SODA

Nightingale

User Handbook



1700 Series

nightingalechairs.com

User Guide Adjustments





ARMS
Fully upholstered arms



B TILT LOCK

To lock in upright position, push lever in towards seat. To unlock, pull lever out



TENSION KNOB

Turn knob clockwise to increase tension, turn counter-clockwise to decrease tension.



PNEUMATIC HEIGHT ADJUSTMENT

To lower, turn the lever while seated. To raise, turn lever with your weight off the seat.



Nightingale Corp. T 1.800.363.8954 F 1.800.637.6784 www.nightingalechairs.com info@nightingalechairs.com