



Disassembly Instruction for Model EC4

**Items are listed in suggested order of disassembly-Estimated Time Required-10 Minutes

STEP	DESCRIPTION	QTY	MATERIAL(S)		TOOL	PROCEDURE
1	Arm caps(L/R)	4	Aluminum	Y	Screwdriver	Pry caps from arm with screw driver
2	Arm to back bolts(L/R)	4	Steel	Y	Allen Key	Using an Allen Key, Remove the 4 bolts which attach the arm to the back
3	the back	1	foam with plywood insert	Y	NA	Recycle
4	arm pad(L/R)	2	polyurethane	Y	Pliers	Using a pliers to remove the arm pad off
5	metal clip to arm bolts	6	Steel	Y	Screwdriver	Using a screwdriver, remove the 6 bolts attach the clips to arm
6	metal clips	6	steel	Y	NA	Recycle
7	Outer seat shell tapping screws	8	Steel	Y	Screwdriver	Using a screwdriver, remove 8 tapping screws which attach the outer seat shell to
8	Outer seat shell	1	PP	Y	NA	Recycle
9	Seat metal bracket to seat plywood bolts	4	Steel	Y	Allen Key	Using a allen key, remove 4 bolts which attach seat bracket to the seat plywood
10	seat foam	1	foam	Y	NA	Recycle
11	seat plywood	1	plywood	Y	NA	Recycle
12	Seat metal bracket to arm bolts	4	Steel	Y	Allen Key	Using a allen key, remove 4 bolts attached to the seat metal bracket to the arm
13	Seat metal bracket	1	Steel	Y	NA	Recycle
14	glider to leg bolts	4	Steel	Y	Screwdriver	Using a screwdriver, remove 4 screws which attach the gliders to the bottom of leg
15	gliders	4	Plastic(nylon)	Y	NA	Recycle

